

Introduction

The uTCA Tester is an automated test suite for testing platform management software implementation of different types of MicroTCA building blocks like, Shelf Manager, Carrier Manager, MCMC, EMMC etc. based of the PICMG Specification MTCA.0 R1.0.

Version 1.1.0.4

Release Date: August 06, 2008

New in this version

This is a maintenance version and does not contain any new feature over v1.1.0.2.

Component Versions

1. **uTCA Tester** : **1.1.0.4**
2. **Miniscope** : **2.0.0.2**

Resolved Issues

Issue #	Summary
1136	uTCA Tester crashes when GET Device Id command is sent at the end of session close.
918	uTCA tester sometimes crashes if the SDR type is wrong.
1097	Syntax error: 'Mtca Tester' object has no attribute 'TestSkipException'.
1126	Some tests complete without any verdict.
1140	uTCA Tester uninstaller does not uninstall the software properly. It causes issues in the next installation.
958	All open sessions (IPMI sessions) were not getting closed after test completion.

Known Issues

Issue #	Summary
508	Authentication types "MD2" and "MD5" are not supported in the current version.
141	"Abort" is not implemented properly. Current behavior: "Abort" prevents the execution of the remaining selected tests after completion of the current test.
456	User defined batch is not being saved across session. Current behavior: User defined batch can be created but will not be saved if the current instance of the Tester is closed.
490	If the software is installed for "All Users", it is not properly installed for users other than the current user.
1152	Statistic functionalities in Miniscope are not complete.