

Introduction

Polaris Networks LTE Load Tester is a test-tool to generate traffic load on an LTE EPC Node to measure and analyze the performance of the node. LTE Load Tester Console allows user to configure testbed, create and play test scenarios by creating one or more surrounding nodes of the EPS system under test (SUT).

Version 1.0.0.2 Beta

Release Date: December 27, 2011

Component Versions

1. LTE Load Tester Console : 1.0.0.2
2. LTE Emulators: 4.1.0.1

New in Release 1.0

1. First Release.

Known Issues

Issue #	Summary
6124	No metric is available for piggybacked bearer creation.
6170	User Guide cannot be opened from the Toolbar on Linux.
6177	Cannot import test-bed configurations and test scenarios easily.